

Assembly manual

Lockable DN50 connection pipes for AQF storage containers





This connection pipe is suitable for AQF 570 and 690 grey, as well as AQF 750 and 1000 blue PE storage containers. The connection pipe has been developed for the on-site connection of the DN50 PE pipe or D=63mm hose.

Only containers of the same size may be connected together!

The following accessories are available:

Article-No.	Name
971765	AQF basic package for 2 tanks with 2 1 ½" taps
971770	AQF extension package with 1 1/2" tap for each subsequent tank
71645	DN50 shut-off valve

Stand DEHOUST/02/2012/mzb The following steps must be carried out to make the connection:

1. Unscrew plug.




2. Screw on the G1 1/2" / S 56x4 adapter.



- Align the tanks to the following spacing intervals:
 AQF 1000 840 mm
 AQF 570, 690, 750 780 mm
- 4. Screw in and align the 1 1/2" shutoff valve using sealing tape.



5. Unscrew the threaded bush with the union nut on the shut-off valve.




6. and using sealing tape screw onto the PP elbow




7. and PP-T-piece.



8. Shorten the pipe Ø 63x920 as required. Recommended pipe length: AQF 1000 760mm AQF 570, 690,750 700mm Connect elbow, pipe Ø 63mm and Tpiece together. Observe tank spacing intervals.



10. Attach the pre-mounted pipe onto the tanks.



Dehoust GmbH * Gutenbergstr. 5-7 * 69181 Leimen * Tel. +49 (0) 6224/9702-0 * Fax +49 (0) 6224/970270 e-Mail: <u>info@dehoust.de</u> * Internet: <u>www.dehoust.de</u>

